

# How to Hang Your Scooped Bed



## What You Will Need

- Small level
- Stud finder (optional but helpful)
- Electric drill with Phillips Standard Bit #2
- Paddle bit, 3/4-inch width
- Phillips head screwdriver

## Contents

- Scooped bed
- Three butterfly toggle bolts
- Three 3-inch wood screws

## Instructions

### Important Tip

If possible, one of the three holes should be mounted in a stud using the provided 3-inch wood screws for maximum security. If this is not possible, the butterfly toggle bolts can be used.

### Mark the wall.

1. Determine where you want to mount your scooped bed.
2. Position the bed on the wall in your desired location. Use a level to ensure it is straight.
3. Place screws through each of the three holes in the back of the bed, and then gently push on the screws to mark the wall. (Three screws are provided to make this marking easier, even though you may not need them all for mounting.)

### Identify studs.

To determine if there is a stud available for mounting, either use a stud finder or drive a screw into the marks you made with the screws.

- If the screw goes through the drywall easily and keeps spinning, there is no stud behind your drywall in that location. Toggle bolts will be needed.
- If the screw hits a stud, it will “grab” it and you will feel resistance. In this case, you will use the provided 3-inch wood screw in that particular hole.

### Drill and hang the bed.

For holes that are **NOT** on a stud:

1. Use the recommended paddle bit to drill holes on your marks.
2. Insert the toggle bolts through the bed then screw the “butterfly” portions on about a quarter of the way.
3. Push the butterfly portions into the corresponding holes until each one pops inside the wall. Gently pull back to ensure the butterfly has “grabbed” inside the wall (see photo).
4. Gently hand-turn the bolt to tighten. **Do not over tighten.**



If one of your holes **IS** on a stud, simply insert the 3-inch wood screw through the hole in the bed and drive it into the wall with an electric drill until it is tight.



**Give the gift of height!**

Smother your new scooped bed with catnip, place treats on it, or use interactive lure-style toys to encourage climbing and exploration!

**Visit [FundamentallyFeline.com](https://www.fundamentallyfeline.com)  
for design ideas!**

**Not a fan of written instructions?  
Watch our “How to Hang Your Wall-Mounted  
Scooped Bed” video at  
[FundamentallyFeline.com/How-to](https://www.fundamentallyfeline.com/How-to) videos!**