

# How to Add a Scooped Bed to the Top of Your Scratching Post



## What You Will Need

- Electric drill with Phillips Standard Bit #2 or Phillips head screwdriver

## Contents

- Scooped bed
- Scratching post and base
- Four 3-inch screws and washers

## Instructions

1. Place washers onto each of the screws.
2. Insert the screws into the pre-drilled holes on the scooped bed. Gently screw them about an inch in to allow for proper alignment on top of the post.
3. Position the scooped bed so that the holes marked “1” and “2” line up with the corresponding holes (also marked “1” and “2”) on the top of the post.
4. Drive screws “1” and “2” into the holes until the bed is flush with the top of the post.
5. Drive the two remaining screws in and secure it tight.

**Note:** When looking down on the scooped bed, you should be able to see the washers. The washers should **NOT** be between the scoop and the wood.

## Ready to use!

Place posts in high-traffic areas where your cats spend time. Scooped beds on posts can be placed near windows for sunning or bird watching. Use treats, catnip, and toys to encourage them to give the post a try. Cats can also easily be clicker trained to use scratching posts.

**Visit [FundamentallyFeline.com](http://FundamentallyFeline.com)  
for more ways to encourage your cats to  
use their new post and bed, info on ideal placement,  
cat care tips, and more great products!**